
Topaz Signature Pad Install

Last Modified on 11/22/2022 10:46 am CST


Agvance supports the T-LBK460-BSB-R Topaz Signature Pad. Follow the instructions below to install this signature pad.

Setup


1. Download and save the SigPlus BSB pad installer to the local client computer or terminal by going here. Right-click the *sigplusbsb.exe*, and choose *Run as Administrator*. Select **Next**.




2. Select Next.




3. Verify the Destination Folder and choose Next.



4. Choose the correct tablet, and select **OK**.



5. After reading the License Agreement, choose Agree.




6. Select **OK** when the BSB TABLET MESSAGE displays.


Note: If the BSB signature tablet is plugged in, unplug it.




7. Select **Extract** on the *FTDI CDM Drivers* window.




8. Select Next.




9. Choose Finish on the Device Driver Installation Wizard window.




10. Select **OK** on the SigPlus Documentation Directory window.



11. Select OK.




12. Choose Yes to add the shortcut to the desktop, and then choose **OK**.



13. Choose **OK**, and the installation will be complete.



- 14. Open Device Manager.
- 15. Expand the *Ports* section, and locate the *USB Serial Port* entry, as shown below. Note which COM port was assigned to this device; this value will be required later in setup.



16. Open the SigPlus.ini file located at C:\Windows\SigPlus.ini. The TabletComPort= value needs to match the COM port in the Device Manager.

```
SigPlus.ini - Notepad — X

File Edit Format View Help

[Tablet]

TabletComPort=9

TabletType=0

TabletLCDMode=0

TabletModel=SigLiteLCD1X5

EnableColor=0

Win95USB=0

ImageScreenResolution=1


UseMultiUSB=0

DisableMessages=0

*
```

Installing On a Terminal Server

- 1. Log into the server using an RDC as Administrator or an equivalent account. Download and save the *SigPlus.exe* file by going here.
- 2. From an elevated CMD line, type change user/install to enter the Install mode.
- 3. Install "SigPlus.exe". Choose your tablet model during install and the COM1 connection type. After installing, from CMD line, type *Change user /execute* or restart server to place server back into "Execute mode" before using the application. (Instructions below are for the supported model)



4. Choose **Next** on the installation window.




5. Choose Next.




6. Verify the Destination Folder is C:\Windows\SigPlus, and then choose Next.




7. Select *T-L* as the Tablet Model Group, and choose **OK**.



8. Choose T-LBK460 or T-L460 as the tablet, and select **OK**.




9. Choose the Com 1 Connection Type. Select OK.




10. Read the License Agreement, and select Agree.




11. Choose Yes to add a shortcut to the desktop, and select OK.



12. Select Finish to complete the installation.




13. After the installation completes, open an elevated CMD line and type Change user /execute.



14. On the terminal server, open the *SigPlus.ini file* located at *C:\Windows\SigPlus.ini*. The *TabletComPort=* value needs to match the COM port the signature pad is using on the workstation.




15. Verify the RDC icon on the workstation is set to forward serial port traffic by editing the icon, navigate to *Local Resources / More*, and then select the *Ports* option.



16. Test the Signature pad outside of Agvance by selecting the DemoOCX icon on the desktop of the workstation or server.



17. Select **Start** on the *Topaz SigPlus Demonstration* window, and start signing the signature pad. If it is configured correctly, the signature will display on the window. If it is not working, double check the comport and the *SigPlus.ini* files.




Agvance Settings for the Signature Pad

The following settings need to be changed for the signature capture window to work in Agvance.


Quick Tickets

Navigate to Accounting / A/R / Manage Quick Tickets / Options, and set Form Type to 40 Character Plain Text. To require a signature for company credit, select the Require Signature for Company Credit option.



Payments

At Accounting / Setup / A/R / Pay Methods, select the pay method for each location that will require a signature.



Bookings

Navigate to Setup/Preferences/AR tab and select the **Design Booking Contracts** to format Booking Contracts. Data Printing Options need both Seller and buyer signature options selected for the signature lines to display on the contract. See Booking Contract Signatures.

Invoices

To print signatures on invoices, check the *Allow signature on save of invoice* box found at the *Setup / Location*Preferences / Invoice tab. The **Capture Signature** button is then available on the *Print Invoice Documents* window. For further information, review the *Allow Signature on Save of Invoice* article.

