

Cut Command on Scale Ticket

Last Modified on 12/21/2022 1:27 pm CST

Q. The Scale Ticket printer has a cut paper function but it is not working.

A. The printer driver for the printer Telpar has a cut paper function that allows the printer to utilize a roll of paper to print scale tickets. Since the driver has a built-in cut command, the printer port should be set to None to allow the printer driver to function. The printer port can be set in the *Scale Interface / Setup / Configure Scale Interface*.

If a port is selected, the printer driver is ignored.